


# Single-Wafer Goldfinger® Velocity for Prelithography Defect Removal



## NAURA Akrion Technology



Patent pending backside megasonics provide high efficiency simultaneous frontside and backside particle removal

Typical process recipe complete in 75 seconds

**NAURA**  
AKRION

## Industry Need

Advanced sub-50nm process requires ArF/Immersion lithography. New process schemes require CVD material which results in an unstable particle level, particularly on the wafer backside. Backside treatment is required.


## Key Benefits

- Reduce lithography rework by removing backside particles which cause depth of field misprints
- Remove frontside and backside particles simultaneously
- Perform post deposition (ARL CVD) and pre-photo cleans in a single step, reducing capital cost as compared to single sided clean



# Prelithography Clean with Backside Megasonics


## Combined Post Deposition and Prelithography Clean




## CVD Process Results in Pattern Misprints




Particles on Wafer Backside




Backside Particles from CVD chuck



Defect inspection and SEM review shows pattern misprint




## Efficient Backside and Frontside Particle Removal



*Si<sub>3</sub>N<sub>4</sub> contamination on Si, 100:1:1 SC1 at 60C for 30s, >100nm particle size measured*

## Lithography Rework Reduction



*Rework ratio SPC chart, before and after inserting Akron Systems megasonics process*

## Single-Wafer and Batch-Immersion Cleaning

NAURA Akron also has a complete line of batch immersion products for a variety of cleaning, etching and stripping applications. Our batch immersion and single wafer systems are found in leading edge fabs worldwide.



NAURA Akron 6330 Hedgewood Drive, Suite 150, Allentown, Pa., USA 18106  
2008Velocity@AKRION SYSTEMS2008. Specifications may change without notice.